

SAMi AC Adapter Instructions

1. If necessary, change the plug adapter. To do this press on the release tab just below the installed adapter and slide it up and off. Select the appropriate plug adapter and slide it on until it clicks in place. This may take some force, press on the release tab if necessary. Make sure it is securely in place before use.
2. Wrap the end of the cord a couple times around the bracket to prevent it from pulling before plugging into the back of the camera.
3. Use the included clips to route the cord along the wall, one every couple feet. First clean the surface with isopropyl rubbing alcohol. Do not use household cleaners. Separate the adhesive strips and remove the blue liner from one. Press the adhesive strip to a clip. Remove the black liner from the adhesive and press the clip on to the wall. Repeat for each clip. The clip opening should be facing up when running the cord horizontally and to the side when running vertically. For best results alternate facing left and right when running up the wall. Press and hold the clip for 30 seconds.
4. To remove a clip, hold it gently while grasping the tab and pull ALONG the wall, stretching the adhesive until it releases.

Strangulation Hazard - do not install within reach of a baby.